



Guide for the Installation & Cleaning

Halcyon Icemakers

**Covering Models
ICE 25 to ICE 130**

THIS MANUAL IS PART OF THE PRODUCT. READ IT CAREFULLY IN ORDER TO USE AND MAINTAIN THE EQUIPMENT CORRECTLY.

IT IS IMPORTANT TO KEEP IT FOR FUTURE TROUBLESHOOTING AND REFERENCE.

INTRODUCTION / WARNING

The installation of this equipment should be done by the Technical Assistance Service department.

The inlet jack should always be placed on an accessible location.

ALWAYS disconnect the power supply from the machine BEFORE any cleaning or maintenance service.

Any change needed on the electrical installation for the appropriate connection of the machine, should be exclusively

performed by qualified and certified professional personnel only.

Any use by the ice maker not intended to produce ice, using drinking water, is considered inappropriate.

It is extremely dangerous to modify or intend to modify this machine, and shall make any type warranty void.

The appliance should only be used by individuals with adequate physical, sensory, and mental abilities, and sufficient experience and knowledge. Those who may have reduced capabilities or lack experience and knowledge should only use it under supervision or after receiving proper instructions.

The appliance should not be operated by Children.

This machine is not intended to be used outdoors nor exposed to the rain.

Connect the equipment to the drinking water network.

The machine should be connected using the power cable supplied with the equipment. The connection is not intended

for fixed cabling.

IT IS MANDATORY TO GROUND THE EQUIPMENT

To avoid possible discharges on individuals or damages to the equipment, the machine should be

grounded pursuant local and/or national regulations as the case may be.

THE MANUFACTURER SHALL BE HELD HARMLESS IN CASE OF DAMAGES ARISING DUE TO THE LACK

OF THE GROUND INSTALLATION.

In order to assure the proper operation and efficiency of this equipment, it is of paramount importance to follow the recommendations of the manufacturer, **SPECIALY THOSE RELATED TO CLEANING AND MAINTENANCE OPERATIONS**, which should be performed mostly by qualified personnel only.

CAUTION:

Do not try to perform repairs. The intervention of non-qualified personnel, besides of being danger.

RECEPTION OF THE MACHINE

Inspect the outside packing. In case of damages, **MAKE THE CORRESPONDING CLAIM TO THE CARRIER.**

To confirm the existence of damages, **UNPACK THE MACHINE IN THE PRESENCE OF THE CARRIER** and state any damage

on the equipment on the reception document, or on a separate instrument.

Always state the machine number and model. This number is printed on three locations:

1.Packing

On the outside, it contains a label with the manufacturing number (1).

2.Exterior of the equipment

On the back of the equipment, there appears a label with the same characteristics as the previous one (1).

3.Nameplate

On the back of the machine.

Check that in interior of the machine the installation kit is complete and comprises:

- Ice scraper, 3/4 gas pipe, 22 mm (0.86 inches) discharge hose, two filters and manual.
- In some models, shims are included.

CAUTION: ALL PACKING ELEMENTS (plastic bags, carton boxes and wood pallets) SHOULD BE KEPT OUTSIDE THE REACH OF CHILDREN, AS THEY ARE A SOURCE OF POTENTIAL HAZARD.

INSTALLATION

THIS ICE MAKER IS NOT DESIGNED FOR OUTDOOR OPERATION.

An incorrect installation of the equipment may cause damages to individuals, animals or other materials, being the manufacturer not responsible for such damages.

CAUTION: The machines are designed to operate at room temperature between 5°C (41°F) and 43°C (109.40°F).


There may be some difficulties in ice- cube removal under the minimum temperatures. Above the maximum temperature, the life of the compressor is shortened and the production is substantially less.


The machines with air-cooler condenser take the air through the front section, and drive it off through the lateral and back louvers.

Do not place anything over the maker or in facing the front louver.

In case the front louver is not enough, the exit is either total or partially obstructed or due to its placement it will receive hot air from another device, we recommend, in case it is not possible to change the location of the machine, **TO INSTALL A WATER CONDENSER. IT IS IMPORTANT THAT THE WATER PIPING DO NOT PASS BY OR NEAR SOURCES OF HEAT SO AS NOT TO LOSE ICE PRODUCTION.**

THREAD THE SUPPORT LEGS TO THE BASE OF THE MACHINE ON THE HOUSING SET TO SUCH END AND REGULATE THE HEIGHT AS TO HAVE THE EQUIPMENT PERFECTLY LEVELED.





1. Water and drainage

Water quality has a remarkable influence on the appearance, hardness and flavor of the ice as well as, on the machines condensed by water, on the life of the condenser.


2. Connections To The Water Network

Use a flexible pipe (1.3 m - 4.27 feet length) with the two filter joints supplied with the machine. We strongly discourage the use of two-exit bibs and two switches as, due to an error could close that back one, leaving the machine without water supply. This could result on a damage call without actually existing one. Pressure should be established between 0.7 Bar (10 / 85 psi.) If pressures overpass such values, install the necessary corrective devices.

3. Connection to Drainage

Drainage should be located lower to the machine level, at 150 mm (5.91 inches) minimum.

It is convenient that the drainage pipe is of 30 mm (1.18 in) of interior diameter and with a minimum gradient of 3 cm (1.18 in) per meter (see figure).



ELECTRICAL CONNECTION

IT IS MANDATORY TO GROUND THE EQUIPMENT.

To avoid possible discharges on individuals or damages to the equipment, the machine should be grounded pursuant local and/or national regulations as the case may be.

THE MANUFACTURER SHALL BE HELD HARMLESS IN CASE OF DAMAGES ARISING DUE TO THE LACK OF THE GROUND INSTALLATION.

The machine is supplied with a 1.5 m (4.92 feet) cable of length. In case the supply cable is damaged, it should be replaced by a cable of special assembly to be furnished by the manufacturer or post-sale service. Such replacement should be performed by qualified technical service only.

The machine should be placed in such a way as to allow a minimum space between the back and the wall to allow an easy access and without risks to the cable jack.

Safeguard the base of the jack.

It is convenient to install adequate switches and fuses.

The line up to the jack should have a minimum section of 2.5 mm² (0.0038 in²)

Voltage and tension are indicated in the nameplate and on the technical specifications of this manual. Variation on voltage above the 10% stated on the nameplate could result on damages or prevent the machine start-up.

START-UP

1. Previous Checkup

- a) Is the machine leveled?
- b) Voltage and frequency are the same as those on the nameplate?
- c) Are the discharges connected and operating?
- d) ** If air condensed: Is the air circulation and its temperature appropriate?

	ROOM	WATER
MAXIMUM	43°C (109.40°F)	35°C (95°F)
MINIMUM	5°C (41°F)	5°C (41°F)

** Is water pressure appropriate?

MINIMUM	0,7 kg./cm ²
MAXIMUM	6 kg./cm ²

NOTE: In case input water pressure is higher than 6 kg/cm², install a pressure reducer. THE BIBB CONNECTION PRESSURE SHOULD NEVER BE REDUCED.

2. Start-up

Once the installation instructions are followed (ventilation, site conditions, temperatures, water quality, etc.), proceed as follows:

- 1) Open the water inlet. Verify the existence of leakages.
- 2) Open the door and remove the protection elements that are inserted on the shield.
- 3) Connect the machine to the electrical network.
- 4) Push the (blue) switch found on the machina front side.
- 5) Verify that there are no vibrations or frictions on the elements.
- 6) Verify that the shield moves freely.
- 7) Verify that the injectors send the water to the evaporator on the right direction (even spread).
- 8) After 10 minutes, verify that the water container has no leakages through the maximum level retainer.
- 9) Verify that after the final cycle, the frost on the aspiration pipe is at 20 mm (0.78 in) of the compressor.

CAUTION:

INSTRUCT THE USER ABOUT MAINTENANCE, INFORMING THAT MAINTENANCE AND CLEANING OPERATION AS WELL AS DAMAGES DUE TO THE LACK OF SUCH OPERATIONS: ARE NOT INCLUDED ON THE WARRANTY.

The technical installer shall invoice traveling costs, hours and materials used on such operations.

MAINTENANCE AND CLEANING INSTRUCTIONS

CAUTION: Maintenance and cleaning operations and damages as the lack of those activities: Are not included on the warranty.

If a good maintenance is performed, the machine will continue producing a good quality ice and will be free of damages.

Maintenance and cleaning intervals will depend on the conditions of the location and water quality.

CAUTION: At least, one revision and cleaning should be performed every six months.

On dusty environments, it might be necessary to clean the condenser on a monthly basis.

**** CAUTION:** For all cleaning and maintenance operations: Disconnect the machine from the power supply.

MAINTENANCE AND CLEANING PROCEDURES

1. Water condenser

- 1) Disconnect the machine.
- 2) Disconnect the water inlet or close the bibb.
- 3) Disconnect the water inlet and outlet from the condenser.
- 4) Prepare a solution at the 50% of phosphoric acid and distilled or demineralized water.
- 5) Make the solution circulate through the condenser. (The solution is more effective if hot - between 35°C 95°F and 40°C 104°F).

DO NOT USE HYDROCHLORIC ACID.

2. Air Condenser

- 1) Disconnect the machine.
- 2) Disconnect the water inlet or close the bibb.
- 3) Clean the louvered area with the help of an aspirator with a brush, non-metallic brush or low-pressure air.

3. Cleaning of the container

- 1) Disconnect the machine, close the water and empty the ice-cube stock.
- 2) Use a dish cloth and bleach with detergent.
- 3) In case the white lime spots remain, rub them with lemon, wait a few minutes and use again a dish cloth. Clear with water, dry and start the machine again.

4. Exterior Cleaning

Use the same procedure as the one indicated for the container.

5. Collectors and Injectors

- 1) Remove the shield. (Take the time to clean it with phosphoric acid, clean with bleach and clear under water).
- 2) Remove the louver of ice drop. (Clean as done with the shield).
- 3) PULL THE COLLECTOR UPWARDS. IT IS PRESSURE MOUNTED.
- 4) Disassemble the injectors and lids, and clean them.
- 5) Disassemble and clean the main head filter. (IT IS PRESSURE MOUNTED).
- 6) Assemble the filter, injectors and collector.

CAUTION: IT IS VERY IMPORTANT WHEN REPLACING THE CONTAINER THAT THE INJECTORS BE PERPENDICULAR, AS IF TWISTED, THE EXTERNAL CUBES COULD RUN OUT OF WATER.

6. Cleaning of the Inlet filters



They are easily obstructed during the first days of operation, MAINLY WITH NEW PIPING INSTALLATIONS. Loose the hose and clean it under water.

7. Water Leak Control

When working on the machine, always check the water connections, status of the clamps and hoses with the purpose of avoiding leakages and prevent damages or floods.

PRACTICO/PRACTICAL/PRAKTISCH/PRACTIQUE

TEORICO/THEORICAL/THEORETISCH/THEORIQUE/FUNZIONALE



VALIDO DESDE EL T1-02-05

PROGRAMADOR

TRANSLATION

Rojo = Red
 Naranja = Orange
 Violeta = Violet
 Azul = Blue
 Negro = Black
 Marron = Brown

COMPONENTES

B	Motor bomba
G	Motor programador
G1	Circuito segund. programador
G2	Circuito programador
H	Presostato seguridad
J	Presostato condens.
K	Electrovalv. condens.(solo agua)
P	Electrovalv. de agua
Q	Electrovalv. gas caliente
R	Motor ventilador
S	Compresor
T1	Termostato almacen
T2	Termostato ciclo
L	Condensador filtro
---	para cond. Agua
---	para ECO100

COMPONENTS

B	Motor pump
G	Cam timer motor
G1	Circuit safety timer
G2	Circuit timer
H	Safety presostat
J	Condens. presostat
K	Condens. electrov. (water)
P	Water electrovalve
Q	Hot gas electrovalve
R	Fan motor
S	Compressor
T1	Stock thermostat
T2	Cycle thermostat
L	Filter condenser
S	Switch on/off
---	for water cond.
---	for ECO100

BESTANDTEILE

B	Motorpumpe
G	Motorprogrammierer
G1	Sicherheitsstromkreis des Program.
G2	Stromkreis des Program.
H	Sicherheitspresostat
J	Presostatopresostat
K	Elektrov. des Kondens. (für Wasser)
P	Elektrov. für das Wasser
Q	Elektrov. für warmes Gas
R	Motorventilator
S	Kompressor
T1	Lagerthermostat
T2	Zyklus thermostat
L	Kondensatorfilter
S	Schalter An/Aus
---	Für Wasser gekühlt
---	Für ECO100

COMPONENTI

B	Motore pompa acqua
G	Motore timer
G1	Sicurezza timer
G2	Timer
H	Presostato sicurezza
J	Presostato sicurezza
K	Elektrovalv. condensatore(acqua)
P	Elektrovalv. acqua
Q	Elektrovalv. gas caldo
R	Motor ventilatore
S	Compressore
T1	Termostato contenitore
T2	Termostato ciclo
L	Condensatore radio disturbi
---	Interruttore generale
---	per cond. Acqua
---	per ECO100

COMPOSANTS

B	Moteur pompe
G	Moteur programmeur
G1	Programmeur securité Circuit
G2	Circuit programmeur
H	Presostat securité
J	Presostat securisation
K	Electrov. condensation (eau)
P	Electrov. eau
Q	Electrov. gaz chaud
R	Moteur ventilateur
S	Compresseur
T1	Thermostat stock
T2	Thermostat cycle
L	Condensateur filtre
---	Interrupteur general
---	pour cond. Eau
---	pour ECO100